

Instruction Manuals

The Burrow, Cottontail and Thumper


www.cotswoldretreats.com






~~Washing machine~~

dishwasher

6. Starting a washing program

Wash Cycle Table

! **NOTE:** () Means: need to fill rinse into the Rinse-Aid Dispenser.

Program	Cycle Selection Information	Description of Cycle	Detergent pre/main	Running time(min)	Energy (Kwh)	Water (L)	Rinse Aid
<i>Intensive</i>	For the heaviest soiled loads, such as pots, pans, casserole dishes and dishes that have been sitting with dried food on them for a while.	Pre-wash(50°C) Pre-wash Wash (65 °C) Rinse Rinse Rinse (55 °C) Drying	$\frac{5}{25g}$ (or3in1)	130	1.4	22	
<i>Normal</i>	For normally soiled loads, such as pots, plates, glasses and lightly soiled pans. standard daily cycle.	Pre-wash(50 °C) Wash (50 °C) Rinse Rinse(65 °C) Drying	$\frac{5}{25g}$ (or3in1)	160	1.2	16	
<i>Eco.</i> (*EN 50242)	For lightly soiled loads, such as plates, glasses, bowls and lightly soiled pans.	Pre-wash Wash (55 °C) Rinse (65 °C) Drying	$\frac{5}{25g}$ (Or3in1)	155	1.05	13	
<i>Rinse</i>	For dishes that need to be rinsed and dried only.	Wash(40°C) Rinse (70 °C) Drying		80	0.8	8	
<i>Glass</i>	For lightly soiled loads, such as glasses, crystal and fine china.	Pre-wash Wash (40 °C) Rinse Rinse (60 °C) Drying	20 g.	95	0.8	15	
<i>Rapid</i>	A shorter wash for lightly soiled loads that do not need drying.	Wash (40 °C) Rinse Rinse (45 °C)	20 g.	30	0.45	12	

! **NOTE:**



*EN 50242 : This programme is the test cycle. The information for comparability test in accordance with EN 50242, as follows:

- Capacity: 12 setting
- Position Upper basket: upper wheels on rails
- Rinse aid setting: 6



Starting and Programmes

Washing machine

Briefly: starting a programme

1. Switch the washing machine on by pressing button . All the LEDs will light up for a few seconds and the ON-OFF/DOOR LOCK Led will begin to flash.
2. Load your laundry into the washing machine and shut the appliance door.
3. Set the PROGRAMME knob to the programme required.
4. Set the wash temperature.
5. Set the spin speed.
6. Add the detergent and any fabric softener.
7. Start the programme by pressing the START/RESET button. To cancel it, keep the START/RESET button pressed for at least 2 seconds.
8. When the programme is finished, the ON-OFF/DOOR LOCK Led will flash to indicate that the appliance door can be opened. Take out your laundry and leave the appliance door ajar to allow the drum to dry thoroughly. Turn the washing machine off by pressing button .

Programme table

Wash cycles	Description of the wash cycle	Max. temp. (°C)	Max. speed (rpm)	Detergents				Max. load (kg)	Residual dampness %	Energy consumption kWh	Total water lt	Cycle duration
				Prewash	Wash	Fabric softener	Bleach					
Standard												
1	White prewash: extremely soiled whites.	90°	1200	●	●	●	-	7	-	-	-	150'
2	White Cotton: extremely soiled whites.	90°	1200	-	●	●	●	7	-	-	-	150'
3	Colour Cotton: lightly soiled whites and delicate colours.	40°	1200	-	●	●	●	7	-	-	-	100'
4	Easy care: heavily soiled resistant colours.	50°	1000	-	●	●	●	3,5	-	-	-	115'
4	Easy care: (3): lightly soiled resistant colours.	40°	1000	-	●	●	●	3,5	46	0.64	53	120'
5	Cotton Standard 60°C (1): heavily soiled whites and resistant colours.	60°	1200	-	●	●	●	7	53	1.16	52,5	205'
6	Cotton Standard 40°C (2): lightly soiled whites and delicate colours.	40°	1200	-	●	●	●	7	53	0.97	75	220'
7	Wool: for wool, cashmere, etc.	40°	800	-	●	●	-	1,5	-	-	-	70'
8	Cotton Standard 20°C: lightly soiled whites and delicate colours.	20°	1200	-	●	●	●	7	-	-	-	170'
Time 4 you												
9	Flash Clean: Heavily soiled whites and fast colours	60°	1200	-	●	●	-	3,5	-	-	-	60'
10	Flash Colours: Lightly soiled whites and delicate colours (shirts, jumpers, etc.)	40°	1200	-	●	●	-	3,5	-	-	-	50'
11	Flash Nylon: Delicate colours (all types of slightly soiled garments)	40°	1000	-	●	●	-	2,5	-	-	-	40'
12	Daily: to refresh lightly soiled garments quickly (not suitable for wool, silk and clothes which require washing by hand).	30°	800	-	●	●	-	3	70	0.16	33	30'
Sport												
13	Special Shoes	30°	600	-	●	●	-	Max. 2 pairs	-	-	-	50'
14	Special Sport	30°	600	-	●	●	-	2,5	-	-	-	60'
Partial programmes												
	Rinse	-	1200	-	-	●	●	7	-	-	-	50'
	Spin + Drain	-	1200	-	-	-	-	7	-	-	-	10'

The length of cycle shown on the display or in this booklet is an estimation only and is calculated assuming standard working conditions. The actual duration can vary according to factors such as water temperature and pressure, the amount of detergent used, the amount and type of load inserted, load balancing and any wash options selected.

1) Test wash cycle in compliance with regulation 1061/2010: set wash cycle 5 with a temperature of 60°C.

This cycle is designed for cotton loads with a normal soil level and is the most efficient in terms of both electricity and water consumption; it should be used for garments which can be washed at 60°C. The actual washing temperature may differ from the indicated value.

2) Test wash cycle in compliance with regulation 1061/2010: set wash cycle 6 with a temperature of 40°C.

This cycle is designed for cotton loads with a normal soil level and is the most efficient in terms of both electricity and water consumption; it should be used for garments which can be washed at 40°C. The actual washing temperature may differ from the indicated value.

For all Test Institutes:

2) Long wash cycle for cottons: set wash cycle 6 with a temperature of 40°C.

3) Long wash cycle for synthetics: set wash cycle 4; with a temperature of 40°C.

Notes

-For programmes 9 and 10, we advise against exceeding a wash load of 3,5 kg.

-For programme 14 we advise against exceeding a wash load of 2,5 kg.

Cotton Standard 20° (wash cycle 8) ideal for lightly soiled cotton loads. The effective performance levels achieved at cold temperatures, which are comparable to washing at 40°, are guaranteed by a mechanical action which operates at varying speed, with repeated and frequent peaks.

Daily (programme 12 for Synthetics) is designed to wash lightly soiled garments in a short amount of time: it only lasts 30 minutes and allows you to save on both time and energy. By setting this programme (13 at 30°C), you can wash different fabrics together (except for woollen and silk items), with a maximum load of 3 kg. We recommend the use of liquid detergent.




Figure 6

1. Before cooking
The LED panel flashes 3 times when plugged into a power supply. You will then see a " : " flashing, prompting you to input the cooking menu and time.

2. Time, Weight/Auto Cooking Knob
You can select auto cooking menu, increase or decrease cooking time and weight during operation by turning **Time, Weight/Auto Cooking Knob**.

3. Pause/Cancel
At the initial stage, press **Pause/Cancel** button once to cancel input programmes and resume initial stage. During cooking, press **Pause/Cancel** button once to stop oven operation and twice to cancel cooking programmes.

4. Clock setting (24 hours)

Setting the clock

1. Press **Preset/Clock** button once.
2. Turn **Time, Weight/Auto Cooking** knob to set exact hours.
3. Press **Preset/Clock** button once again.
4. Turn **Time, Weight/Auto Cooking** knob to set exact minutes.
5. Press **Preset/Clock** button once again or wait for 5 seconds, and the number will gradually change.

5. Auto reminder
When your preset cooking procedure has finished, the LED display will show "End" and then three beeps sound to prompt you to take out the food. If you do not press **Pause/Cancel** or open the door then the three beeps will sound at an interval of 3 minutes.

6. Child lock function
Use this feature to lock the control panel when you are cleaning or so that children cannot use the microwave unsupervised. **You will not be able to use the buttons in this mode.** To set the child lock, press and hold **Pause/Cancel** button for about 3 seconds until the LED display shows a key symbol. To cancel the child lock, press and hold **Pause/Cancel** button for about 3 seconds until the key symbol disappears.

7. Microwave cooking

Press **Micro Power** button, LED display shows P100-P80-P60-P40-P20

P100-- High power; 100% microwave power. For quick and thorough cooking such as meat and vegetables.

P80-- Medium High power; 80% microwave power. For medium express cooking, such as eggs, fish, rice and soup.

P60-- Medium power; 60% microwave power. For steaming foods.

P40-- Medium low power; 40% microwave power. For defrosting foods.

P20-- low power; 20% microwave power. For keeping foods warm.

Please note:

- 1) The max time which can be set is 60 minutes.
- 2) Never use the grill rack during microwave cooking.
- 3) Never operate the oven empty.
- 4) If you turn the food during operation, press the **Instant/Start** button once and the preset cooking procedure will continue.
- 5) If you intend to remove the food before the preset time, you must press **Pause/Cancel** button once to clear the preset procedure to avoid unintended operation of the next time use.

8. Express
Press **Express** button, the LED display to shows 0:30-1:00-1:30. This function will allow you to heat liquids easily. Choose the proper time depending the volume of the liquid.
0:30 --- default, 30 seconds
1:00 --- default 1 minute operation time
1:30 --- default time is 1 minute and 30 seconds.

9. Grill

Press **Grill** button to select the light grill mode, which is for grilling meat such as sausages, steak & chicken.
Please note: It is not necessary to preheat when using the grill function.

Example: To grill food with Light grill for 10 minutes

1. After power-up, the colon flashes or press **Pause/Cancel** button once
2. Select the desired cooking menu by pressing **Grill** button
3. Set cooking time by turning **Time/Weight/Auto Cooking** knob
4. Press **Instant/Start** button to start, and LED will count down to show running time.

10. Grill combi

Press **Grill combi** button to select either the **Grill combi 1 - Grill combi 2** or **Grill combi 3**

Grill combi 1---30% microwave cooking time while 70% grilling time.
Grill combi 2---55% microwave cooking time while 45% grilling time.
Grill combi 3---70% microwave cooking time while 30% grilling time.

Warning

In the Grill combi mode, the microwave as well as the grill rack and cooking containers will become very hot. Caution when removing any item from the microwave oven. Use pot holders or oven mitts to prevent burns.

11. Auto Defrost

Press **Auto defrost** button, the LED display shows **D.1-D.2-D.3**

- D.1** For defrosting poultry between 0.2Kg to 3.0Kg.
- D.2** For defrosting meat between 0.1Kg to 2.0Kg
- D.3** For defrosting seafood between 0.1Kg to 0.9Kg

1. It is necessary to turn over the food during defrosting, to ensure it defrosts evenly.
2. Defrosting food usually takes longer the cooking foods.

Example:

1. After power-up, the colon flashes or press **Pause/Cancel** button once
2. Select the food kind by pressing **Auto Defrost** button
3. Set defrosting weight by turning the **Time, Weight/Auto Cooking** knob
4. Start cooking by pressing **Instant/Start** button. LED will count down to show running time.
5. Half way during defrosting 3 beep sound will be heard two times to prompt you turn over the food. Open the door and turn over the food and shield the warm portion. Press **Instant/Start** button again to continue the defrosting. If you do not when an audible signal sounds, the defrosting cycle will continue until the time count down to 0.

12. Auto cooking

The oven has a default cooking menu for simple operation. When the LED display flashes with a colon turn the **Time/Weight/Auto Cooking** knob, LED cycles to show **AC-1, AC-2, AC-3...AC-8**. Choose the menu according to the food type and weight of food.

Example:

- After power-up, the colon flashes or press **Pause/Cancel** button once
- Choose the appropriate menu by turning **Weight/Time/Auto Cooking** knob
- Press **Instant/Start** button once to confirm
- Turn **Weight/Time/Auto Cooking** knob to select the desired one among the given weight.
- Start cooking by pressing **Instant/Start** button, and LED will count down to show remaining time.

Display



13. Automatic starting (delay function)

If you do not want the menu be started immediately, you can preset the cooking menu and time and the preset menu will be automatically started at your set time.

Example: Now it is 12:30 clock, if you want that the microwave oven to start automatically cooking with 100P microwave power for 9 minutes at 14:20

1. Set the current time	Display
1.1 Press Preset/Check button	0 : 0 0
1.2 Turn Time/Weight/Auto Cooking knob to set hours, and hours will be flashed	1 2 : 0 0
1.3 Press Preset/Check button again	1 2 : 0 0
1.4 Turn Time/Weight/Auto Cooking knob to set minutes	1 2 : 3 0
1.5 Press Preset/Check button or waiting for 5 seconds, and the numbers will go steadily.	1 2 : 3 0

NOTE: Delay function is not applicable for express , auto cook and auto defrost.

14. Multi-sequence cooking

To obtain best cooking result, some recipes need to different amounts of time to cook.

Example: You want to cook food with 100P microwave for 3 minutes then light grill for 9 minutes. This is 2 sequences setting.

1. 100P microwave for 3min	Display
1.1 Press Micro Power button to select desired menu	P 1 0 0
1.2 Turn Time/Weight/Auto Cooking knob to set cooking time	3 : 0 0
1.3 Start cooking by pressing Instant/Start button	Light grill
2. Light grill for 9min	Display
2.1 Press Grill button	G
2.2 Turn Time/Weight/Auto Cooking knob to set cooking time	9 : 0 0
2.3 Start cooking by pressing Instant/Start button	Light grill

When 100P microwave power cooking is finished, microwave oven will begin light grill automatically.

Note: Max 4 sequences can be set per time by repeating step 1 and step2 optionally if you like to set more.

Important Safety Instructions.

Please read carefully and keep for future reference.

Before cooking food or liquids in your microwave oven, please check that the following safety precautions are taken.

- DO NOT use any metallic cookware in the microwave oven:
 - Metallic containers
 - Dinnerware with gold or silver trimmings
 - Skewers, forks, etc

Reason: Electric arcing or sparking may occur and may damage the oven.

- DO NOT heat:
 - Airtight or vacuum-sealed bottles, jars, containers, excludes baby food jars
 - Airtight food, excludes eggs, nuts in shells and tomatoes

Reason: The increase in the pressure may cause them to explode
Tips: Remove lids and pierce skins, bags etc.

- DO NOT operate the microwave oven when its empty.

Reason: The walls may be damaged
Tips: Leave a glass of water inside the oven at all times. The water will absorb the microwaves if you accidentally set the oven going when it is empty.

- DO NOT cover the rear ventilation slots with cloth or paper.

Reason: The cloth or paper may catch fire as hot air is evacuated from the oven.

- ALWAYS use oven gloves when removing a dish from the oven.

Reason: Some dishes absorb microwaves and heat is always transferred from the food to the dish. The dishes are therefore hot.

- DO NOT touch heating elements or interior oven walls.

Reason: These walls may be hot enough to burn even after cooling has finished, even though they do not appear to be so. Do not allow inflammable materials to come into contact with any interior area of the oven. Let the oven cool down first.

- To reduce the risk of the fire in the oven cavity.
 - Do not store flammable materials in the oven.
 - Remove wire twist ties from paper or plastic bags
 - Do not use your microwave oven to dry newspapers
 - If smoke is observed, keep the oven door closed and switch off or disconnect the oven from the power supply.

- Take particular care when heating liquids and baby foods.
 - ALWAYS allow a standing time of at least 20 seconds after the oven has been switched off so that the temperature can equalize.
 - Stir during heating, if necessary, and ALWAYS stir after heating.
 - Take care when handling the container after heating. You may burn yourself if the container is too hot.
 - A risk of delayed eruptive boiling exists.
 - To prevent delayed boiling and possible scalding, you should put a plastic spoon or glass stick into the beverages and stir before, during and after heating.

Reason: During the heating of liquids the boiling point can be delayed; this means that eruptive boiling can start after the container is removed from the oven. You may scald yourself.


- Immerse the scalded area in cold water for at least 10 minutes
- Cover with a clean, dry dressing
- Do not apply any creams, oils or lotions.

NEVER fill the container to the top and choose a container that is wider at the top than at the bottom to prevent the liquid from boiling over. Bottles with narrow necks may also explode if overheated.

ALWAYS check the temperature of the baby foods or milk before giving it to a baby.


Blue room

3.0 Front panel controls




- 1. Standby**
Illuminates red to indicate the unit has entered standby.
- 2. Pre-set 1-4**
Touch here to choose or set pre-sets
- 3. Source selection**
Touch here to switch between *DAB*/*FM*/*Bluetooth*/*Line* input
- 4. Volume keys**
Touch here to increase or decrease the volume.
- 5. Enter key**
DAB - Select radio station
Bluetooth - Play / Pause
Menu - Enter
- 6. Forward and back keys**
DAB - Station + / -
FM - Tune frequency
Bluetooth - Skip track
Menu - Next / Prev item
- 7. Menu**
- 8. Change display information**
- 9. Set alarms and on/off**


5.0 Listening to a connected *Bluetooth* music source



6.0 Listening to DAB Radio



7.0 Storing pre-sets



4.0 Pairing a Bluetooth device

