


# Panel above TV in Lounge

## 3.0 Front panel controls



### 1. Standby

Illuminates red to indicate the unit has entered standby.

### 2. Pre-set 1-4

Touch here to choose or set pre-sets

### 3. Source selection

Touch here to switch between *DAB*/*FM*/*Bluetooth*/*Line* input

### 4. Volume keys

Touch here to increase or decrease the volume.

### 5. Enter key

*DAB* - Select radio station

*Bluetooth* - Play / Pause

Menu - Enter

### 6. Forward and back keys

*DAB* - Station + / -

*FM* - Tune frequency

*Bluetooth* - Skip track


Menu - Next / Prev item

### 7. Menu


### 8. Change display information

### 9. Set alarms and on/off


## 4.0 Pairing a *Bluetooth* device



## 5.0 Listening to a connected *Bluetooth* music source






## 6.0 Listening to DAB Radio




# Washing Machine

Table of programmes

PROGRAMME	kg (MAX.) * (see control panel)				°C (MAX.)	1) 		
	6 kg	7 kg	8 kg	9 kg		2		1
All In One 20°C	4	4,5	5,5	6	20°	●	●	
All Hygiene	4	4,5	5,5	6	60°	●	●	
All In One 59 Min.	6	7	8	9	40°	●	●	
<i>good Quick wash</i> * Rapid <sup>3)</sup> 14-30-44 Min.	* 14'	1	1	1,5	1,5	30°	●	●
	30'	2	2,5	2,5	2,5	30°	●	●
	* 44'	3	3,5	3,5	3,5	40°	●	●
Dark Colours	3	3,5	4	4,5	40°	●	●	(●)
Wool	1	1	2	2	40°	●	●	
Handwash & Silk	1	1	2	2	30°	●	●	
Rinse	-	-	-	-	-	△	●	
Drain + Spin	-	-	-	-	-			
Shirts <sup>2)</sup>	3	3,5	4	4,5	30°	●	●	(●)
Delicates	2	2,5	2,5	2,5	40°	●	●	
Mixed <sup>2)</sup>	3	3,5	4	4,5	60°	●	●	(●)
 Cottons <sup>**</sup> <sup>2)</sup>	6	7	8	9	60°	●	●	(●)
Whites <sup>2)</sup>	6	7	8	9	90°	●	●	(●)
Sports	2,5	3	3,5	4	30°	●	●	(●)

## Digital Display

The display's indicator system allows you to be constantly informed about the status of the machine.



### 3) WASH TEMPERATURE INDICATOR LIGHTS

This shows the washing temperature of the selected programme that can be changed (where allowed) by the relevant button. If you want carry out a cold wash all the indicators must be off.

#### 4) CYCLE DURATION

When a programme is selected the display automatically shows the cycle duration, which can vary, depending on the options selected.

Once the programme has started you will be kept informed constantly of the time remaining to the end of the wash.

The appliance calculates the time to the end of the selected programme based upon a standard loading, during the cycle, the appliance corrects the time to that applicable to the size and composition of the load.

#### 5) STAIN LEVEL INDICATORS LIGHTS

Once the programme has been selected, the indicator light will automatically show the stain level set for that programme.

Selecting a different stain level the relevant indicator will light up.

#### 6) OPTIONS INDICATOR LIGHTS

The indicator lights show the option that can be selected by the relevant button.

#### 7) KEY LOCK INDICATOR LIGHT

The indicator light show that the keys are locked.

#### 8) WI-FI (some models only)

In the models with the Wi-Fi option, the icon indicates that the Wi-Fi system is working.

### 1) DOOR LOCKED INDICATOR LIGHT

The indicator light is illuminated when the door is fully closed.

Close the door BEFORE selecting the START/PAUSE button.

When **START/PAUSE** is pressed on the machine with the door closed, the indicator will flash momentarily and then illuminate.

If the door is not properly closed, the light will continue to flash for about 7 seconds, after which the start command will be automatically delete. In this case, close the door in the proper way and press the **START/PAUSE** button.

Wait until the **DOOR LOCKED** light has gone out before opening the door.

### 2) SPIN SPEED

This show the spin speed of the selected programme that can be changed or omitted by the relevant button.

For all the information about the functionality and the instructions for an easy configuration of the Wi-Fi, please refer to the "Download" section on <http://wizardservice.candy-hoover.com>.

### 9) Kg MODE (function active only on certain programmes)

During the first minutes of the cycle, the "Kg MODE" indicator remain on while the intelligent sensor will weigh the laundry and adjust the cycle time, water and electricity consumption accordingly.

Through every wash phase "Kg MODE" allows to monitor information on the wash load in the drum and in the first minutes of the wash it:

- adjusts the amount of water required;
- determines the length of the wash cycle;
- controls rinsing according to the type of fabric selected to be washed it;
- adjusts the rhythm of drum rotation for the type of fabric being washed;
- recognizes the presence of lather, increasing, if necessary, the amount of water during rinsing;
- adjusts the spin speed according to the load, thus avoiding any imbalance.


EN





MICROWAVE

4.1 Control panel



4.2 Operating instructions

4.2.1 Setting the time

When the microwave oven is energized, "0:00" will be displayed in LED screen and buzzer will ring once.

1. Press (Kitchen Timer/Clock) twice and the figures for hours will start flashing.
2. Turn to adjust the hour; the input value should be between 0 and 23.
3. Press and the figures for minutes will start flashing.
4. Turn to adjust the minutes; the input value should be between 0 and 59.
5. Press (Kitchen Timer/Clock) to finish time setting, ":" symbol will flash, and the time will light.

If you press (Stop/Cancel) during time setting, oven will automatically return back to previous mode.

4.2.2 Cooking with microwave oven

1. Press (Microwave) and "P100" will be displayed in LED screen.
2. Press (Microwave) again or turn to select the desired power. Each time you press the key, "P100", "P80", "P50", "P30" or "P10" will be displayed respectively.

3. Press (Start/+30 Sec./Confirm) to confirm and turn to set the cooking time to a value between 0:05 and 95:00.
4. Press (Start/+30 Sec./Confirm) again to start cooking.

**Example:** If you want to use 80% microwave power to cook for 20 minutes, you can operate the oven with the following steps.

5. Press (Microwave) once and "P100" will be displayed in the screen.
  6. Press (Microwave) once again or turn to set 80% microwave power.
  7. Press (Start/+30 Sec./Confirm) to confirm and "P 80" will be displayed in the screen.
  8. Turn to adjust the cooking time until the oven displays "20:00".
  9. Press (Start/+30 Sec./Confirm) to start cooking.
- The steps for adjusting the time in coding button are as below:

Setting the duration	Increment amount
0-1 minutes	5 seconds
1-5 minutes	10 seconds
5-10 minutes	30 seconds
10-30 minutes	1 minute
30-95 minutes	5 minutes

4.2.3 Microwave keypad instructions

Order	Screen	Microwave Power
1	P100	100%
2	P80	80%
3	P50	50%
4	P30	30%
5	P10	10%

4.3 Cooking with grill or combination mode

1. Press (Grill/Combination) and "G" will be displayed in LED screen. Press (Grill/Combination) repeatedly or turn to select the desired power. Each time you press the key, "G", "C-1" or "C-2" will be displayed respectively.
2. Press (Start/+30 Sec./Confirm) to confirm and turn to set the cooking time to a value between 0:05 and 95:00.
3. Press (Start/+30 Sec./Confirm) again to start cooking.

**Example:** If you want to use 55% microwave power and 45% grill power (C-1) to cook for 10 minutes, you can operate the oven with the following steps.

1. Press (Grill/Combination) once and "G" will be displayed in the screen.
2. Press (Grill/Combination) once again or turn to select the Combination 1 mode.
3. Press (Start/+30 Sec./Confirm) to confirm and "C-1" will be displayed in the screen.



## 4 Operation

- Turn to adjust the cooking time until the oven displays "1:00".
- Press (Start/+30 Sec./Confirm) to start cooking.

### 4.3.1 (Grill/Combination) Keypad instructions

Order	Screen	Microwave Power	Grill Power
1	G	0%	100%
2	C-1	55%	45%
3	C-2	36%	64%

When half the grill time passes, the oven sounds twice, and this is normal. In order to have a better grilling effect, you should turn the food over, close the door, and then press (Start/+30Sec./Confirm) to continue cooking. If no operation is performed, the oven will continue cooking.

### 4.4 Quick start

- In standby mode, press (Start/+30Sec./Confirm) to start cooking with 100% microwave power. Each time you press the key, cooking time will increase until 95 minutes with steps of 30 seconds.
- In microwave oven cooking, grill and combination cooking or defrost by time modes, the cooking time will increase by 30 seconds each time you press (Start/+30 Sec./Confirm).

- In standby mode, turn counterclockwise to set the cooking time in order to start cooking with 100% microwave power and press (Start/+30Sec./Confirm) to start cooking.

In auto menu and defrost by weight modes, pressing (Start/+30Sec/Confirm) will not increase the cooking time.

### 4.5 Defrost by weight

- Press (Defrost by weight) for once.
- Turn to select the weight of food from 100 to 2000 g.
- Press (Start/+30 Sec./Confirm) to start defrost.

### 4.6 Defrost by time

- Press (Defrost by time) for once.
- Turn to select the defrost time. The maximum time is 95 minutes.
- Press (Start/+30 Sec./Confirm) to start defrost. Defrost power is P30 and cannot be changed.

### 4.7 Kitchen timer (counter)

Your oven is equipped with an automatic counter which is not linked with the oven functions and can be used separately at the kitchen (it can be set to max. 95 minutes.)

## 4 Operation

- Press (Kitchen Timer/Clock) for once and 00:00 will be displayed in LED screen.
  - Turn to enter the correct time.
  - Press (Start/+30Sec./Confirm) to confirm the setting.
  - When the countdown from the entered time reaches to 00:00, the buzzer will ring for 5 times. If the time is set (24-hour system), current time will be displayed in LED screen.
- Press (Stop/Cancel) to abort the timer at any time.

Kitchen timer functions different than 24-hours system. Kitchen timer is just a timer.

### 4.8 Auto menu

- Turn clockwise to select the desired menu. Menus between "A-1" and "A-8", namely pizza, meat, vegetable, pasta, potato, fish, beverage and popcorn, will be displayed.
- Press (Start/+30Sec./Confirm) to confirm.
- Turn to choose the default weight in accordance with the menu chart.
- Press (Start/+30 Sec./Confirm) to start cooking.

- Turn clockwise until "A-6" is displayed in the screen.
- Press (Start/+30Sec./Confirm) to confirm.
- Turn to select the weight of fish until "350" is displayed in the screen.
- Press (Start/+30 Sec./Confirm) to start cooking.

**Example:** If you want to use "Auto Menu" to cook 350 g fish:

## 4 Operation

### 4.8.1 Auto cooking menu

Menu	Weight	Screen
A-1 Pizza	200 g	200
	400 g	400
A-2 Meat	250 g	250
	350 g	350
	450 g	450
A-3 Vegetable	200 g	200
	300 g	300
	400 g	400
A-4 Pasta	50 g (with 450 ml cold water)	50
	100 g (with 800 ml cold water)	100
A-5 Potato	200 g	200
	400 g	400
	600 g	600
A-6 Fish	250 g	250
	350 g	350
	450 g	450
A-7 Beverage	1 glass (120 ml)	1
	2 glasses (240 ml)	2
	3 glasses (360 ml)	3
A-8 Popcorn	50 g	50
	100 g	100

## 4 Operation

### 4.9 Multi-step cooking

At most 2 steps can be set for cooking. In multi-step cooking, if one step is defrosting, then defrosting must be placed in the first step.

**i** If you want to thaw food for 5 minutes and then cook with 80% microwave power for 7 minutes, perform the following steps:

1. Press (Defrost by time) for once.
2. Turn to select the defrost time until "5:00" is displayed in the screen.
3. Press (Microwave) once and "P100" will be displayed in the screen.
4. Press (Microwave) once again or turn to set 80% microwave power.
5. Press (Start/+30Sec./Confirm) to confirm and "P 80" will be displayed in the screen.
6. Turn to adjust the cooking time until the oven displays "7:00".
7. Press (Start/+30Sec./Confirm) to start cooking. Buzzer will sound once for the first step and defrost time countdown will start. Buzzer will sound once again when entering the second cooking step. Buzzer will sound for 5 times at the end of cooking.

### 4.10 Query function

1. In microwave, grill and combination modes, press (Microwave) or (Grill/Combination) and the current power level will be displayed for 3 seconds. After 3 seconds, the oven will return to the previous mode.
2. While cooking, press (Kitchen Timer/Clock) and the current time will be displayed for 3 seconds.

### 4.11 Child lock

1. **Locking:** In standby mode, press (Stop/Cancel) for 3 seconds and a buzzer will sound indicating that the child lock is activated. If the time is already set, current time will also be displayed; otherwise will be displayed in the LED screen.

2. **Unlocking:** To disable the child lock, press (Stop/Cancel) for 3 seconds and a long "beep" will sound indicating that the child lock is disabled.

### 4.12 Opening the oven door

1. Press (Open door) and the oven door will be opened.

**i** If the door cannot be opened with "open door" key in model MGB 25333 BG (e.g., due to power failure), you can open the door with vacuum lifter for opening the door manually.

## How to operate the oven

### General information on baking, roasting and grilling



#### WARNING

Hot surfaces cause burns!

Product may be hot when it is in use. Never touch the hot burners, inner sections of the oven, heaters and etc. Keep children away. Always use heat resistant oven gloves when putting in or removing dishes into/from the hot oven.

#### DANGER:

Be careful when opening the oven door as steam may escape. Exiting steam can scald your hands, face and/or eyes.

### Tips for baking


- Use non-sticky coated appropriate metal plates or aluminum vessels or heat-resistant silicone moulds.
- Make best use of the space on the rack.
- Place the baking mould in the middle of the shelf.
- Select the correct rack position before turning the oven or grill on. Do not change the rack position when the oven is hot.
- Keep the oven door closed.

### Tips for roasting

- Treating whole chicken, turkey and large piece of meat with dressings such as lemon juice and black pepper before cooking will increase the cooking performance.
  - It takes about 15 to 30 minutes longer to roast meat with bones when compared to roasting the same size of meat without bones.
  - Each centimeter of meat thickness requires approximately 4 to 5 minutes of cooking time.
  - Let meat rest in the oven for about 10 minutes after the cooking time is over. The juice is better distributed all over the roast and does not run out when the meat is cut.
  - Fish should be placed on the middle or lower rack in a heat-resistant plate.
- Gas level temperature conversion chart

Gas level	1	2	3	4	5	6	7	8	9
Temperature in °C	140	150	165	180	200	220	240	260	280

### How to operate the main gas oven (LHS)



The gas oven is operated by the gas oven control knob. In off position (top) the gas supply is Off.

#### Switch on the gas oven

The gas oven is ignited with the ignition button.

1. Open oven door.
2. Set the timer for a cooking time.



If the timer is not set, the oven will not work. The timer is set only LHS bottom oven.

2. Keep gas oven control knob pressed and turn it counterclockwise.
3. Press ignition button and release it again.
4. Keep the gas oven control knob pressed for 3 to 5 seconds.
- » Repeat the process until the emanating gas is ignited.
5. Keep the gas oven control knob pressed for another 3 to 5 seconds. Be sure that gas has ignited and flame is present.
6. Select the desired baking power/ gas mark.
7. If there is no electricity, ignite the gas with the gas lighter from the ignition control hole.



#### DANGER

There is the risk of gas compression and explosion!

Do not attempt to ignite the gas more than 15 seconds. If the burner is not ignited within 15 seconds, turn off the knob and wait for 1 minute. Ventilate the room before reattempting to ignite the burner. There is the risk of gas compression and explosion!

#### Switch off the gas oven

1. Turn gas oven control knob to off position (top).


### How to operate the oven timer

#### The timer controls only main oven



#### WARNING

After energizing the product, please wait at least three minutes before first cooking.



1. Program knob
2. Cooking time
3. Alarm period
4. Minus key
5. Plus key
6. Screen brightness adjustment
7. Alarm volume
8. Current time
9. Keylock
10. Adjustment key

### Adjusting cooking time

In this operation mode, you may adjust the time period during which the oven will operate (cooking time).

1. Place your dish in the oven.
  2. Keep gas oven control knob pressed and turn it counterclockwise.
  3. Press ignition button and release it again.
  4. Keep the gas oven control knob pressed for 3 to 5 seconds.
  - » Repeat the process until the emanating gas is ignited.
  5. Keep the gas oven control knob pressed for another 3 to 5 seconds. Be sure that gas has ignited and flame is present.
  6. Select the desired baking power/ gas mark.
  7. For cooking time, press **7** key to activate cooking time symbol **'2'**.
  8. Adjust the cooking time using **4** and **5** keys.
  - » Cooking symbol shall be on (will be displayed continuously) after cooking time is set.
  9. After the cooking process is completed, cooking time symbol **'2'** will start to flash and the alarm signal will start to sound. The gas flow will cut off.
  10. Alarm signal will be on for 2 minutes. To stop the alarm signal, just press any key.
  - » Alarm will be silenced and current time will be displayed.
  10. Do not forget to turn off the oven using oven knob.
- In order to cancel adjusted cooking time:**
1. To reset the cooking time, press **7** key to activate cooking time symbol **'2'**.
  2. Press and hold the key **4** until **"0,00"** is displayed.

**While cancelling the cooking time, if main oven is on, it will still be on after cancelling the cooking time.**

#### How to use the program lock

You can prevent using of clock buttons by activating the program feature.

**When the keylock function is activated, clock buttons except for "10" key cannot be used.**



1. Press '10' key to activate keylock symbol "g".

» "OFF" will be displayed.

2. Press 5 key to activate the keylock.

» After the keylock has been adjusted, "ON" will be displayed and the keylock symbol will stay on.

**Deactivate the program lock**

1. Press '10' key to activate keylock symbol "g".

» "ON" will be displayed.

2. Press '4' key to deactivate the keylock.


» "OFF" will be displayed after the keylock is turned off.

**How to use the alarm clock**

In addition to using the timer for cooking, it can be also used as a reminder or an alarm clock. As soon as the defined period of time has expired, the alarm clock will emit a signal. The alarm clock has no influence on the functions of the oven.

**Setting the alarm clock**

1. Press 7 key to activate alarm time symbol (3).

 The maximum alarm time can be 23 hours and 59 minutes.

2. Adjust the alarm time using 4 and 5 keys.

» Alarm symbol will be on (will be displayed continuously) after alarm time is set, and the alarm time will be displayed.

3. After the alarm time is finished, alarm symbol will start flashing and an alarm will start to sound.

**Switching off the alarm**

1. To stop the alarm signal, just press any key.  
 » Alarm will be silenced and current time will be displayed.

**In order to cancel set alarm time;**

1. To reset the alarm time, press 7 key to activate alarm time symbol (3).

2. Press and hold the key 4 until "0,00" is displayed.

 Alarm time will be displayed. If the alarm time and cooking time are set concurrently, shortest time will be displayed.

**Changing alarm sound adjustment**

1. Press '10' key to activate alarm sound adjustment symbol (7) for alarm volume adjustment.


2. Adjust the desired sound using '4' and '5' keys.

» Selected alarm sound level will be displayed as "b-01", "b-02" or "b-03" on the screen.

**Cooking times table for LHS -main oven**

1st rack of the oven is the bottom rack.

 Maximum load capacity of oven tray: 4 kg (8.8 lb).

 The timings in this chart are meant as a guide. Timings may vary due to temperature of food, thickness, type and your own preference of cooking.

Stand dishes on a baking sheet to prevent spillages onto oven base and help keep oven clean.

**Baking and roasting**

Food	Preheating *	Insertion level	Control knob position	Cooking time
Roast beef; Sirloin, topside, topump, rib	10 min.	2	5	20..40 mins then per 450 g/lb + 30 mins Medium 20 mins then per 450 g/lb + 20 mins, Well done 25 mins then per 450 g/lb + 25 mins
Roast Lamb; Leg, shoulder, rack, breast, whole rack, ribs <sup>†</sup>	10 min.	2	5	20..40 mins then per 450 g/lb + 20 mins
Roast pork; loin, shoulder, leg	10 min.	2	5	20..40 mins then per 450 g/lb + 25 mins
Roast chicken	10 min.	2	5-6	30..40 mins then per 450 g + 20 mins
Roast turkey	10 min.	2	5-6	30..40 mins then per 450 g + 25 mins
Casseroles	-	2	4	2..3 hours
Whole fish	10 min.	2	4	25..35 mins <sup>‡</sup>
Pasta Bake	10 min.	3	4-5	30..40 mins <sup>‡</sup>
Fruit pies (200mm)	10 min.	3	4	25..35 mins <sup>‡</sup>
Pizza	10 min.	3	4	30..40 mins, depending on thickness <sup>‡</sup>
Small cakes - One tray	10 min.	3	4	30..50 mins
Victoria sandwich	10 min.	3	4	30..50 mins
Biscuits	10 min.	3	4-5	15..25 mins
Scones	10 min.	3	4-5	15..25 mins
Rich fruit cake (20-22cm)	10 min.	3	3	3..4 hours

\* at control knob position 7<sup>†</sup> depending on quantity /<sup>‡</sup> depending on size

## How to operate the top grill (LHS)

**WARNING**  
Hot surfaces may cause burns! Keep children away from the product. Oven door remains slightly inclined when opened full and thus, possible splashes to not reach you.


**WARNING**  
This product is designed for OPEN DOOR GRILLING.



1. Door switch
2. Cut-off valve

**i** The grill door has a cut-off valve (2). As a safety feature, this valve prevents the grill from working when the door is closed.


### For products with cooling fan



Cooling fan  
Control panel

While open door grilling, in order to protect control panel, knobs and related oven parts, a fan automatically starts working.

**i** Because of the door switch, fan continues working until the grill door closed.



The grill is operated by the grill control knob. In off position (top) the gas supply is locked. When the door fully open, it remains tilted slightly, so that any spillage will be directed away from you.

### Switch on grill

- The gas grill is ignited with the ignition button.
1. Open oven door.
  2. Keep grill control knob **pressed** and turn it in **counterclockwise** onto the grill symbol.
  3. Press ignition button and release it again. » Repeat the process until the gas is ignited.
  4. Keep the grill control knob pressed for another 3 to 5 seconds.
  5. Be sure that ignited and flame occurred.
  6. If there is no electricity, ignite the gas with the gas lighter direct to grill burner.



**DANGER**  
There is the risk of gas compression and explosion!  
Do not attempt to ignite the gas more than 15 seconds. If the burner is not ignited within 15 seconds, turn off the knob and wait for 1 minute. Ventilate the room before reattempting to ignite the burner. There is the risk of gas compression and explosion!

### Switching off the grill

1. Turn the Grill control knob to Off (upper) position.



Do not use the top rack for grilling.



Foods that are not suitable for grilling carry the risk of fire. Only grill food which is suitable for intensive grilling heat. Do not place the food too far in the back of the grill. This is the hottest area and fatty food may catch fire.

### Cooking times table

- If food is cooking too quickly, it can be placed in the bottom of the grill pan.
- Do not place cookware with rough bases on the oven door.
- Ensure that there is at least 25mm space at top of oven when grilling larger foods or cookware.
- Do not place aluminium foil on the wire rack to grill on.

### Grilling with gas grill

Food	Preparation/setting	Grilling time #
Toast	Place on wire rack in grill pan.	1-3 mins
Bacon	Place on wire rack in grill pan.	3-6 mins
Garrmon steaks	Place on wire rack in grill pan.	8-15 mins
Beefburgers	Place on wire rack in grill pan.	8-15 mins
Sausages	Place on wire rack in grill pan.	6-10 mins
Chops, chicken pieces	Place on upturned wire rack in grill pan.	15-30 mins
Fish fillers, fish fingers	Place on wire rack in grill pan.	10-20 mins
Grilling /browning tops of foods e.g. cottage pie	Place on base of top oven.	3-6 mins

# depending on size resp. thickness

- Turn food over to ensure it is cooked on both sides
- Preheat oven first



1st rack of the oven is the bottom rack.




Do not use the top rack for grilling.



The timings in this chart are meant as a guide. Timings may vary due to temperature of food, thickness, type and your own preference of cooking.

## How to operate the RHS oven



### Select temperature and operating mode

1. Set the Function knob to the desired temperature.

» Oven heats up to the adjusted temperature and maintains it. During heating and cooling, thermostat light turns on.

### Switching off the electric oven

Turn the Function knob to Off (top) position.

**i** Ensure you stand back from the appliance when opening the oven door to allow any build up of steam or heat to escape.

- Check food is thoroughly cooked and is piping hot.
- As a fan oven heats up more quickly and generally cooks food at a lower temperature than a conventional oven, preheating the oven is often unnecessary. However, food such as bread, scones, Yorkshire pudding, do benefit from being placed in a pre-heated oven.


### Cooking times table for Grill (LHS)

**i** The values indicated in the table below are data indicative. They may vary according to the type of food as well as your preferences of cooking.

Dish	Cooking level number	Rack position	Temperature (°C)	Cooking time (approx. in min.)
**Cakes in tray	One level	4	175	30... 45
**Cakes in mould	One level	4	175	30... 50
**Cakes in cooking paper	One level	4	180... 170	20... 30
**Sponge cake	One level	4	180... 200	10... 20
**Cakes	One level	4	160... 170	20... 30
**Dough pastry	One level	4	200	20... 30
**Rich pastry	One level	4	190	25... 35
**Leaven	One level	4	190	20... 40
**Lardona	One level	4	180	25... 45
**Pizza	One level	4	200	15... 25
Beef steak (Whole) / Roast	One level	4	25 min. 220, then 180... 190	80... 120
Leg of Lamb (casseroie)	One level	4	25 min. 220, then 180... 190	70... 100
Roasted chicken	One level	4	15 min. 220, then 190	65... 75
Turkey (Sliced)	One level	4	25 min. 220, then 190	70... 120
Fish	One level	4	200	20... 30

### Baking and roasting

**i** Level 1 is the bottom level in the oven.



#### Recommended cooking levels:

- For 1 tray use 6th level.
- For 2 trays use 4 and 6th levels.
- For 3 trays homogeneous cooking use 2-4-6 levels.
- For 4 trays cooking use 2-4-6-8 levels. For 8 th level please cook more than 2-4-6 trays.